## **Load Limits**

Following are the load limits for your motorcycle:

## Maximum weight capacity:

```
Includes the weight of the rider, = 200 kg (441 lbs) passenger, all cargo and all accessories
```

Putting too much weight in individual storage compartments can also affect stability and handling. So be sure to stay within the limits given below:

## Maximum weight:

travel trunk	= 9.0  kg  (20.0  lbs)
each saddlebag	= 9.0 kg (20.0 lbs)
each fairing pocket	= 2.0 kg (4.5 lbs)
each trunk side pocket	= 0.5 kg (1.0 lbs)
of all cargo	= 32 kg (71 lbs)

The weight of added accessories will reduce the maximum cargo weight you can carry.

## **Loading Guidelines**

Improperly loading your motorcycle can affect its stability and handling. Even if your motorcycle is properly loaded, you should ride at reduced speeds and never exceed 130 km/h (80 mph) when carrying cargo.

Follow these guidelines whenever you carry a passenger or cargo:

- Check that both tyres are inflated properly.
- If you change your normal load, you may need to adjust your rear suspension settings (page 27) and your headlight (page 73).
- To prevent loose items from creating a hazard, make sure that storage lids are properly closed and that any other cargo is securely tied down before you ride away.