



Warning Indicators ON or Flashing ► ABS (Anti-lock Brake System) Indicator

ABS (Anti-lock Brake System) Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the brake system. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes ON or starts flashing while riding.
- Indicator does not come ON when the ignition switch is in the ON position.
- Indicator does not go OFF at speeds above 10 km/h (6 mph).

If the ABS indicator stays ON, your brakes will continue to work as a conventional system, but without the anti-locking function.

The ABS indicator may flash if you turn the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch OFF and then ON again. The ABS indicator will go OFF after your speed reaches 30 km/h (19 mph).

Troubleshooting