










## 2 Clock setting:

- 1 Press the **SEL**  (up) button or the **SEL**  (down) button until the desired hour is displayed.
  - ▶ Press and hold the **SEL**  (up) button or the **SEL**  (down) button to advance the hour fast.



- 2 Press the **MODE** button. The minute digits start flashing.



- 3 Press the **SEL**  (up) button or the **SEL**  (down) button until the desired minute is displayed.
  - ▶ Press and hold the **SEL**  (up) button or the **SEL**  (down) button to advance the minute fast.



- 4 Press the **MODE** button. The clock is set, and then the display moves to the backlight brightness adjustment.