

Tire Puncture u Removing Wheels

4. Tighten the right axle pinch bolts to hold the axle.
5. Tighten the axle nut.

Torque: 48 lbf·ft (65 N·m, 6.6 kgf·m).

6. Loosen the right axle pinch bolts.
7. Tighten the left axle pinch bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

8. Install the right brake caliper and tighten new mounting bolts.

Torque: 33 lbf·ft (45 N·m, 4.6 kgf·m).

9. Install the left brake caliper and tighten new mounting bolts.

Torque: 33 lbf·ft (45 N·m, 4.6 kgf·m).

- u Take care to prevent the brake caliper from scratching the wheel during installation.
- u Use new mounting bolts when installing the brake caliper.

NOTICE

When installing a wheel or caliper into original position, carefully fit the brake disc between the pads to avoid scratching them.

10. Lower the front wheel on the ground.
11. Apply the brake lever several times. Then, pump the fork several times.
12. Retighten the right axle pinch bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).