

### **Clutch Lock Mechanism (XL200 SUPER FARMER)**

Lock the clutch lock lever with the clutch lever pulled all the way.

To unlock, pull and release the clutch lever so that the clutch can be engaged.

**CAUTION:** Proper free play should be maintained. To prevent an abrupt start, apply the brakes when starting.

### **Brake Lock Mechanism (XL200 SUPER FARMER)**

Lock the brake lock lever with the brake lever pulled all the way.

To unlock, pull and release the brake lever so that the brake can be disengaged.

**CAUTION:** Proper free play should be maintained. To prevent an abrupt start, apply the brakes when starting.

---

### **Mecanismo de trabado del embrague (XL200 SUPER FARMER)**

Trabar la palanca de trabado del embrague con la palanca del embrague completamente apretada.

Para soltar, tirar y liberar la palanca del embrague de forma que éste quede embragado.

**PRECAUCION:** Mantener el juego libre apropiado. Aplicar los frenos al arrancar para evitar un arranque brusco.

### **Mecanismo de trabado del freno (XL200 SUPER FARMER)**

Trabar la palanca de trabado del freno con la palanca del freno completamente apretada.

Para soltar, tirar y liberar la palanca del freno de forma que éste quede desembragado.

**PRECAUCION:** Mantener el juego libre apropiado. Aplicar los frenos al arrancar para evitar un arranque brusco.