

INSTALLATION

Install the new gasket.
install the muffler and exhaust pipe assembly, then temporarily install the all mounting fasteners.

Tighten the exhaust pipe joint nuts.



Tighten the exhaust pipe mounting bolt.



Tighten the muffler mounting bolt to the specified torque.

TORQUE: 13 N·m (1.3 kgf·m, 9 lbf·ft)

