

Install the chain slider.  
Install the collar and tighten the screw to the specified torque.

**TORQUE: 5.9 N·m (0.6 kgf·m, 4.3 lbf·ft)**



Place the drive chain adjusters into the swingarm.



## INSTALLATION

Install the swingarm onto the frame.  
Install the swingarm pivot bolt to the frame from the left side.

Temporarily tighten the swingarm pivot nut.



Install the chain cover to the swingarm by aligning the chain cover boss with the groove on the swingarm.

