

INSTALLATION

CAUTION:

Be careful not to damage the radiator core.

Install the radiator assembly, aligning its grommets with the bosses on the upper and lower brackets.



Install and tighten the radiator mounting bolt.



Connect the fan motor sub-harness 2P (Natural) connector.
Connect the lower radiator hose.



Connect the upper radiator hose.
Connect the siphon tube and air bleed tube to the radiator.

