

Instruments *(Continued)*

2 Clock setting:

- 1 Press the **SEL** button until the desired hour is displayed.

▶ Press and hold to advance the hour fast.



- 2 Press the **SET** button. The minute digits start flashing.



- 3 Press the **SEL** button until the desired minute is displayed.
▶ Press and hold to advance the minute fast.



- 4 Press the **SET** button. The clock is set, and then the display moves to the backlight brightness adjustment.