


## Preparation

Before starting, insert the key, turn the ignition switch ON and confirm the following:

- The transmission is in neutral.  
( neutral indicator light ON).
- The engine stop switch is set to  (RUN).
- The low oil pressure indicator is ON.
- The PGM-FI indicator is off.
- The coolant temperature indicator is OFF.
- The Immobilizer System (HISS) indicator is OFF.
- The ABS indicator is ON (see page 19) (CBF1000A).

The low oil pressure indicator should go off a 2-3 seconds after the engine starts. If the light keeps flashing, stop the engine immediately and check the engine oil level.

### NOTICE

Operating the engine with insufficient oil pressure can cause serious engine damage .