


Installation Notes:

Position the front wheel between the fork legs and insert the axle from the left side, through the left fork leg and wheel hub.

CAUTION: When installing the wheel, fit the left brake disc carefully between the brake pads to avoid damaging the pads.

Position the tang on the speedometer gearbox against the tang (7) on the right fork leg.



Notes pour la repose:

Mettre la roue avant en position entre les pattes de fourche et insérer l'axe par le côté gauche, à travers la patte de fourche gauche et le moyeu de roue.

PRÉCAUTION: Lors de la repose de la roue, placer le disque de frein gauche soigneusement entre les plaquettes de frein pour éviter d'endommager les plaquettes.

Mettre la languette sur le boîtier de pignon de compteur de vitesse en place contre la languette (7) sur la patte de fourche droite.