OPERATION

PRE-RIDE INSPECTION

AWARNING

* If the Pre-ride Inspection is not performed, severe personal injury or vehicle damage may result.

Inspect your motorcycle every day before you ride it. The items listed here will only take a few minutes to inspect, and in the long run they can save time, expense, and possibly your life.

- 1. Engine oil level—add engine oil if required (page 29). Check for leaks.
- 2. Fuel level—fill fuel tank when necessary (page 26). Check for leaks.
- 3. Coolant level—add coolant if required. Check for leaks (pages 23—24).
- Front and rear brakes—check operation; make sure there is no brake fluid leakage (pages 18—21).
- 5. Tyres—check condition and pressure (pages 30—32).
- Drive chain—check condition and slack (pages 66—70). Adjust and lubricate if necessary.

- 7. Throttle—check for smooth opening and closing in all steering positions.
- Lights and horn—check that headlight, tail/stoplight, turn signals, indicators and horn function properly.
- Engine stop switch—check for proper function (page 34).
- 10. Side stand ignition cut-off system—check the proper function (page 72).
- 11. Battery electrolyte—check the level and add if necessary (page 81).

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.