


HEADLIGHT AIM VERTICAL ADJUSTMENT


Vertical adjustment can be made by turning the screws (1) and (2) in or out as necessary.

Obey local laws and regulations.

Except E, U:



For E, U:



- | | |
|-----------------------|----------|
| (1) Screw (low beam) | (A) Up |
| (2) Screw (high beam) | (B) Down |