

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Fuel indicator
- (2) Neutral indicator
- (3) Left turn signal indicator
- (4) Immobilizer system (HISS) indicator
< Except MX, IIMX type >
- (5) Tachometer
- (6) Tachometer red zone indicator
- (7) Tachometer red zone
- (8) Right turn signal indicator
- (9) High beam indicator
- (10) Malfunction indicator (MIL)
- (11) Multi-function display
- (12) Odometer/Tripmeter display
- (13) RESET button
- (14) SEL button

