(Ref.No.) Description	Function
(13) RESET button	Use this button for the following purposes.
	• To adjust time
	To reset tripmeter
	• To change unit of speedometer, odometer and
	tripmeter (E, IIIE, VIE type only)
	• To change setting of the tachometer red zone
	10 change setting of the tachometer red zone
	indicator activation revolution and indication
	pattern
	• To display the total mileage of the odometer when
	you drive 100,000 kilometers (miles) or more
)
(14) SEL button	Use this button for the following purposes.
(11) SEE SUCCO	• To adjust time
	• To switch blinking of the immobilizer system
	(HISS) indicator (except MX, IIMX type)
	To change indication of tripmeter A and B
	• To change setting of the tachometer red zone
	indicator activation revolution and indication
	pattern
	pattern