

# MAINTENANCE

page

## 95 MAINTENANCE

- 95 THE IMPORTANCE OF MAINTENANCE
- 96 MAINTENANCE SAFETY
- 97 SAFETY PRECAUTIONS
- 98 MAINTENANCE SCHEDULE
- 101 TOOL KIT
- 102 SERIAL NUMBERS
- 103 COLOUR LABEL
- 104 ENGINE OIL
- 110 THROTTLE OPERATION
- 111 COOLANT
- 112 DRIVE CHAIN
- 118 DRIVE CHAIN SLIDER
- 119 FRONT AND REAR SUSPENSION INSPECTION
- 120 SIDE STAND
- 121 WHEEL REMOVAL
- 127 BRAKE PAD WEAR
- 129 BATTERY
- 131 FUSE REPLACEMENT

page

- 134 BRAKELIGHT SWITCH ADJUSTMENT
- 135 BULB REPLACEMENT

## 142 CLEANING

## 147 STORAGE GUIDE

- 147 STORAGE
- 149 REMOVAL FROM STORAGE

## 150 SPECIFICATIONS

## 154 CATALYTIC CONVERTER