

(Ref.No.) Description	Function
(14) Combined ABS indicator (amber) 〈CBR1000RR ABS〉	This indicator normally comes on when the ignition switch is turned ON, and goes off after you ride the motorcycle at speed above 10 km/h (6 mph). If there is a problem with the Combined ABS, this indicator lights or flashes and remains on (page 95).
(15) Control button B	Use this button for the following purposes. <ul style="list-style-type: none"> • To change indication of current fuel mileage, average fuel mileage, and fuel consumption (page 31) • To change unit of speedometer, odometer, tripmeter and fuel mileage meter (E type only) (page 34) • To change indication mode of fuel mileage (page 35) • To change the reset mode of tripmeter A and fuel mileage meter (page 33) • To adjust time (page 36). • To change setting of the tachometer red zone indicator activation revolution and indication pattern (page 38)