

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
* FUEL LINE						I		I		I	—
* THROTTLE OPERATION						I		I		I	113
* AIR CLEANER		NOTE (2)					I			I	—
* SPARK PLUGS											—
											EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R
* VALVE CLEARANCE								I			—
ENGINE OIL				R		R		R		R	107
ENGINE OIL FILTER				R		R		R		R	109
RADIATOR COOLANT		NOTE (3)				I		I		R	53
* COOLING SYSTEM						I		I		I	114
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—