

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								97-102
DRIVE CHAIN SLIDER					I			I		I	103
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R	26-28
BRAKE PAD WEAR					I	I	I	I	I	I	114
BRAKE SYSTEM				I		I		I		I	26-28, 116
* BRAKE LIGHT SWITCH						I		I		I	122
* HEADLIGHT AIM						I		I		I	63
CLUTCH SYSTEM						I		I		I	29
CLUTCH FLUID		NOTE (3)			I	I	R	I	I	R	29
SIDE STAND						I		I		I	105
* SUSPENSION						I		I		I	104
* NUTS, BOLTS, FASTENERS				I		I		I		I	-
** WHEELS/TYRES						I		I		I	-
** STEERING HEAD BEARINGS				I		I		I		I	-