

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	DRIVE CHAIN		I, I EVERY 1,000km (600mi)								100
	DRIVE CHAIN SLIDER				I			I		I	106
	BRAKE FLUID	NOTE (3)		I	I	R	I	I	R		34
	BRAKE PAD WEAR			I	I	I	I	I	I		116
	BRAKE SYSTEM		I		I		I		I		34, 116
*	BRAKE LIGHT SWITCH				I		I		I		—
*	HEADLIGHT AIM				I		I		I		—
	CLUTCH SYSTEM		I	I	I	I	I	I	I		37
	SIDE STAND				I		I		I		108
*	SUSPENSION				I		I		I		107
*	NUTS, BOLTS, FASTENERS		I		I		I		I		—
**	WHEELS/TYRES				I		I		I		—
**	STEERING HEAD BEARINGS		I		I		I		I		—