

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								76
DRIVE CHAIN SLIDER					I		I		I	82	
BRAKE FLUID		NOTE (3)		I	I	R	I	I	R	19	
BRAKE PAD WEAR				I	I	I	I	I	I	93	
BRAKE SYSTEM			I		I		I		I	19, 92	
* BRAKE LIGHT SWITCH					I		I		I	—	
* HEADLIGHT AIM					I		I		I	—	
CLUTCH SYSTEM			I	I	I	I	I	I	I	23	
SIDE STAND					I		I		I	84	
* SUSPENSION					I		I		I	81	
* NUTS, BOLTS, FASTENERS			I		I		I		I	—	
** WHEELS/ TYRES					I		I		I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	