

# CONTENTS

- 1 SCOOTER SAFETY
  - 1 Safe Riding Rules
  - 3 Protective Clothing
  - 4 Modifications
  - 4 Load and Accessories
- 7 LOCATION OF INSTRUMENTS
- 10 INSTRUMENTS AND INDICATORS
- 17 MAIN COMPONENTS (Information you need to operate this scooter)
  - 17 Suspension
  - 18 Brakes
  - 23 Liquid Coolant
  - 25 Fuel
  - 28 Engine Oil
  - 29 Tubeless Tires
- 33 ESSENTIAL COMPONENTS
  - 33 Ignition Switch
  - 34 Right Handlebar Controls
  - 35 Left Handlebar Controls
  - 36 Idle Stop Switch (@ 125/150 ES)
  - 37 Rear brake lock
- 38 FEATURES (Not required for operation)
  - 38 Steering Lock
  - 39 Seat Lock
  - 40 Helmet Holder
  - 41 Center Compartment
  - 42 Document Compartment
  - 43 Front Fairing
  - 43 Lower Central Cover
  - 44 Left/right side cover
  - 45 Headlight vertical Adjustment
  - 46 Idle stop (@ 125/150 ES)
- 52 RUNNING YOUR SCOOTER
  - 52 Pre-ride Inspection
  - 53 Starting the Engine
  - 56 Running in
  - 57 Riding
  - 64 When the Idle Stop Switch is Set in the IDLING STOP Position (@ 125/150 ES)
  - 67 Parking
  - 68 Anti-theft Advice