

Rif. No.	Description	Function
1	Fuel gauge	Shows approximate fuel supply available (see page 14).
2	Left turn indicator	Flashes when left turn signal is used.
3	Speedometer	Indicates driving speed.
4	Odometer	Indicates total number of kilometers run.
5	Digital clock	Shows hours and minutes (see page15).
6	High beam indicator (blue)	Lights up when high beam is on.
7	Right turn signal indicator	Lights when the right light turn signal operates.
8	Coolant temperature gauge	Shows coolant temperature (see page 13).
9	Maintenance indicator	When the ignition is turned to ON the indicator lights up and after a few seconds turns off. If the indicator remains on, it means it is time to change the engine oil. Refer to the Maintenance Table (page 70). If the warning lamp does not come on it means there is a fault in the indicator signal system (page16).