

## Tire wear/replacement

See your Honda dealer

### **⚠ WARNING**

- The use of tires other than those listed on the tire information label may adversely affect handling.
- Do not install tube-type tires on tubeless rims. The beads may not seat and the tires could slip on the rims, causing tire deflation that may result in a loss of vehicle control.
- Do not install a tube inside a tubeless tire. Excessive heat build-up may cause the tube to burst resulting in rapid tire deflation that may result in a loss of vehicle control.

### **⚠ WARNING**

- Replace the tire if the sidewall is punctured or damaged. Sidewall flexing may cause repair failure and tire deflation may result in a loss of vehicle control.
- If nails or rocks are allowed to remain stuck in the tire's tread surface, performance will be reduced and late repair may not fully restore the tire's designed safety level.

### CAUTION

- Do not try to remove tubeless tires without special tools and rim protectors. You may damage the rim sealing surface or disfigure the rim.