

HELMET HOLDER

The helmet holder means you do not need to carry your helmet after parking the scooter.

Insert the ignition key into the seat lock, and turn it clockwise to unlock.


Hang the helmet by routing either end of the helmet holder wire through the helmet's D-ring.

Hook the loops of the wire onto the helmet holder (1) and lower the seat lock.

The helmet holder wire is furnished in the tool kit.

⚠ WARNING

- **The helmet holder is designed for helmet security while the vehicle is parked. Do not ride with a helmet attached to the holder as the helmet may interfere with safe running and result in loss of control.**



(1) Helmet holder