

## MAINTENANCE SCHEDULE

The following maintenance schedule specifies all maintenance required to keep your scooter in peak operating condition. Maintenance work must be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your Honda dealer meets all of these requirements.

Perform the Pre-ride Inspection at each scheduled maintenance period.

I: Inspect and clean, adjust, lubricate or replace if necessary

C : Clean R: Replace A: Adjust L: Lubricate

Frequency	Whichever comes first	Odometer reading (Note 1)					
		x 1000 km x 1000 mi	1 0.6	4 2.5	8 5	12 7.5	See page
Element	Note	Month		6	12	18	
* Fuel line				I	I	I	—
* Throttle operation				I	I	I	—
* Air cleaner	Note 2					R	76
Crankcase breather	Note 3			C	C	C	—
Spark plug					R		84
* Valve clearance			I	I	I	I	—
Engine oil			R	R	R	R	81
Engine oil filter						C	82
* Engine idle speed			I	I	I	I	86
Radiator coolant	Note 4				I		—