

Fuses	
Location	111
Replacement	111
G	
Gasoline (see Fuel)	
Gearshift pedal	23
Gearshifting	23, 59
H	
Headlight switches	20
Helmet holder	29
High altitude carburetor adjustment	97
Hills	
Riding across slopes	74
Riding down hills	72
Riding up hills	65
Stopping on hills	67
Turning on slopes	75
I	
Idle speed adjustment	95
Ignition switch	13
Indicator lamps	
Neutral indicator lamp	22
Reverse indicator lamp	22
Inspection, pre-ride	36
K	
Kick starter	17
L	
Loading	
Loading guidelines and procedures	40
Weight limits	39
Lubrication (see Engine oil and Final drive oil)	
M	
Maintenance	