

## MAINTENANCE SCHEDULE

	ITEMS	FREQUENCY	Whichever comes first ⇒	INITIAL MAINTENANCE		REGULAR MAINTENANCE INTERVAL		Refer to page
				mi	100	600	1200	
				km	150	1000	2000	
		NOTE	HOURS	20	100	200		
EMISSION RELATED ITEMS	* FUEL LINE					I	—	
	* THROTTLE OPERATION					I	86	
	AIR CLEANER	(NOTE 1)			C	C	87–89	
	AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	90	
	SPARK PLUG				I	I	105	
	* VALVE CLEARANCE				I	I	I	106
	ENGINE OIL				R	R	R	24,94–96
	ENGINE OIL FILTER				R	R	R	97–100
	* ENGINE OIL STRAINER SCREEN IN OIL TANK						C	—
	* ENGINE IDLE SPEED				I	I	I	91

I: Inspect and Clean, Adjust,  
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate