

# MAINTENANCE

page

<b>85</b>	<b>MAINTENANCE</b>
85	THE IMPORTANCE OF MAINTENANCE
86	MAINTENANCE SAFETY
87	SAFETY PRECAUTIONS
88	MAINTENANCE SCHEDULE
91	TOOL KIT
92	SERIAL NUMBERS
93	COLOUR LABEL
94	AIR CLEANER
95	ENGINE OIL
99	SPARK PLUGS
104	THROTTLE OPERATION
105	IDLE SPEED
106	COOLANT
107	DRIVE CHAIN
112	DRIVE CHAIN SLIDER
113	FRONT AND REAR SUSPENSION INSPECTION
114	SIDE STAND
115	WHEEL REMOVAL
122	BRAKE PAD WEAR
124	BRAKE SYSTEM INSPECTION

page

125	BATTERY
127	FUSE REPLACEMENT
130	STOPLIGHT SWITCH ADJUSTMENT
131	BULB REPLACEMENT
<b>138</b>	<b>CLEANING</b>
<b>143</b>	<b>STORAGE GUIDE</b>
143	STORAGE
145	REMOVAL FROM STORAGE
<b>146</b>	<b>SPECIFICATIONS</b>
<b>150</b>	<b>CATALYTIC CONVERTERS</b>
<b>151</b>	<b>NOISE CONTROL SYSTEM (AUSTRALIA ONLY)</b>