

Speedometer/Odometer/Tripmeter

Speedometer

Shows riding speed.


Odometer/Tripmeter

The odometer (2) shows accumulated mileage.

The tripmeter shows mileage per trip.

There are two tripmeters, tripmeter A (3) and tripmeter B (4). Switch between the odometer, tripmeter A and tripmeter B by pressing the RESET button (5) repeatedly.

To reset the tripmeter, push and hold the RESET button (5) with the display in the tripmeter A or tripmeter B mode.



- (1) Speedometer
- (2) Odometer
- (3) Tripmeter A
- (4) Tripmeter B
- (5) RESET button