


Speed and Mileage Unit Change

(E, EK type only)

The speedometer displays both “km/h” and “mph”.

The odometer/tripmeter displays both “km” and “mile”.

Push and hold the SELECT button (1) for more than 2 seconds to select “km/h”/“km” or “mph”/“mile”.



(1) SELECT button