

⚠ WARNING

- * *Do not downshift when traveling at a speed that would force the engine to overrev in the next lower gear; the rear wheel may lose traction, resulting in a possible loss of vehicle control.*

CAUTION:

- * *Do not shift gears without disengaging the clutch and closing the throttle. The engine and drive train could be damaged by overspeed and shock.*
- * *Do not tow the motorcycle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.*
- * *Do not exceed 13,500 rpm when running the engine without a load. Serious engine damage may result.*

NOTE:

- * The battery will not charge while the engine speed is below 1,500 rpm. Avoid idling for prolonged periods, or continuous operation below 1,500 rpm.

- * Be careful when revving the engine or accelerating in 1st or 2nd gear as the engine will easily enter the tachometer red zone.