
- 6. Remove the drive chain (9) from the driven sprocket by pushing the rear wheel forward.
- 7. Remove the rear axle shaft (10), side collars and rear wheel from the swingarm.



- (7) Drive chain adjusting bolt
- (9) Drive chain (10) Rear axle shaft