

4. To end the adjustment, press the **CLOCK** button 5 seconds after the last adjustment, or turn the ignition switch **OFF**.