


HEADLIGHT AIM VERTICAL ADJUSTMENT

Vertical adjustment can be made by turning the bolt (1) in or out as necessary.

Obey local laws and regulations.



(1) Knob

(A) Up

(B) Down