

5. Tyres – check condition and pressure (pages 38 – 43 ).
6. Drive chain – check condition and slack (page 94 ). Adjust and lubricate if necessary.
7. Throttle – check for smooth opening and full closing in all steering positions.
8. Lights and horn – check that headlight, tail/brake light, turn signals, indicators and horn function properly.
9. Engine stop switch – check for proper function (page 49 ).
10. Side stand ignition cut-off system – check for proper function (page 102 ).