

Instruments *(Continued)*

If the ignition switch is turned to the OFF position or none of the **MODE**, **SEL** ▲ (up) and **SEL** ▼ (down) buttons is pressed for about 30 seconds, the control is automatically switched from the setting mode to the ordinary display.


If the buttons are not pressed for about 30 seconds, items in the process of being set will be discarded and only items where settings have been finalized will be applied.

Only if the ignition switch is turned to the OFF position will items in the process of being set and those that are finalized be applied.

1 Time format setting:

You can switch the time format between 12 hour format or 24 hour format.

- 1 Turn the ignition switch to the ON position.
- 2 Select the ADJUST mode. ➔ P.32
▶ The current time format start flashing.
- 3 Press the **SEL** ▲ (up) button or the **SEL** ▼ (down) button to select "12hr" or "24hr".



- 4 Press the **MODE** button. The time format is set, and then the display moves to the clock setting.