






Instruments (Continued)

5 Switch sign setting

You can set the switch sign with a multi color line.

When the **SEL**  (up) button, **SEL**  (down) button, **MODE** button or Torque Control switch is pressed, the multi color line will light briefly when the setting is on.

- 1 Press the **SEL**  (up) button or the **SEL**  (down) button to select "On" or "OFF".
 - ▶ The message of "SW SIGN" scrolls in INFO 1 display.



- 2 Press the **MODE** button. The switch sign is set, and then the display will return to the ordinary display.

Multi color line information setting

You can show the riding conditions by setting the multi color line information.

One of the following items can be selected in this setting.

- Color OFF mode
- Rev up linkage mode (white color mode)
- Rev up linkage mode (color mode)
- ECO mode
- Gear position linkage mode
- Riding mode linkage mode

