

Stopping .....	107
Environment.....	113

**F**

Flooded Engine .....	32
Front Brake Lever Adjustment.....	78
Front Seat .....	55
Front Suspension .....	79

**Fuel**

Mileage meter.....	22
Recommended.....	34
Remaining.....	28
Tank Capacity.....	34

Fuses.....	47, 102
------------	---------

**G**

Gasohol.....	121
Gasoline.....	34

**H**

Headlight Aim.....	83
Headlight Dimmer Switch .....	30
Helmet Holder.....	35

HESD (Honda Electronic Steering Damper) .....	108
High Beam Indicator.....	26
High Coolant Temperature Indicator.....	20, 86
Honda Contacts .....	126
Horn Button .....	30

**I****Ignition Cut-off System**

Banking Sensor .....	107
Side Stand.....	69

Ignition Key .....	106
--------------------	-----

Ignition Switch .....	31, 32, 107
-----------------------	-------------

Indicators.....	26
-----------------	----

Information Record .....	132
--------------------------	-----

Instruments .....	18
-------------------	----

**L**

Labels.....	7
-------------	---

Load Limits .....	15
-------------------	----

Loading Guidelines.....	15
-------------------------	----

Lower Fairing .....	57
---------------------	----