## **Instruments** (Continued)



## Tripmeter [A/B] & Fuel mileage meter & Fuel consumption meter

**SEL** button selects the tripmeter A, tripmeter B, current fuel mileage, average fuel mileage and fuel consumption.

► To reset the tripmeter: ► P. 26

