

Instruments *(Continued)*


Lap Timer

You can display and record lap time, fuel consumption, travel distance, driving time, and average fuel mileage.

Press **SEL** button and **SET** button at the same time when the motorcycle is stopped. The ordinary display switches to the lap time mode. **➡ P.37**

Press and hold **SEL** button when the motorcycle is stopped. The display switches between the lap time mode and lap time recall mode. **➡ P.39**

To return to the ordinary display, press **SEL** button and **SET** button at the same time when the motorcycle is stopped.



SEL button press and hold ⇒

SEL button and **SET** button press ➡