Instruments (Continued) Measurement of lap time






Start/lap button

SET button


- ! Switch the display to the lap time mode.(P36)
- ! Press SET button or start/lap button then start measuring.

While measuring 1 lap



Press start/lap button at each lap.

In completion of 1 lap



In completion of 21 laps



- ! Press **SET** button to end the measurement.
 - During the measurement, switching to other modes is not available.