

Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch in the ON position with the engine stopped will drain the battery.

Do not turn the key while riding.

Engine Stop Switch

Do not use the engine stop switch except in an emergency. Doing so when riding will cause the engine to suddenly turn off, making riding unsafe.

If you stop the engine using the engine stop switch, turn the ignition switch to the OFF position. Failing to do so will drain the battery.

Odometer

The display locks at 999,999 when the read-out exceeds 999,999.

Tripmeter

The tripmeters return to 0.0 when each read-out exceeds 9,999.9.

Document Bag

CBR1000RR/RA

The owner's manual, registration, and insurance information can be stored in the plastic document bag on the underside of the rear seat. ➤ P. 113, ➤ P. 140

CBR1000S1/S2

The owner's manual, registration, and insurance information can be stored in the plastic document bag on the underside of the single seat cowl. ➤ P. 113, ➤ P. 141