










Function lever

- Push forward or pull backward to adjust the audio system volume.  **P.150**
- Push forward or pull backward to adjust the grip heater level.  **P.127**

Voice control switch / **Page switch**


- Push forward to receive, reject or end a call.  **P.183**
- Push forward to start Siri if Apple CarPlay is available.  **P.198**
- Pull backward and hold to go to the Home screen or Apple CarPlay screen.  **P.36**
- Pull backward to return to the riding information or audio screen.  **P.38**

Headlight dimmer/Passing light control switch

-  : High beam
-  : Low beam
-  **PASS** : Flashes the high beam headlight.

Shift up switch (+)

CRF1100D/D4

To shift up the gear.  **P.209**