
## **Crankcase Breather**

Refer to Safety Precautions on page 43.

Service more frequently if your motorcycle is ridden in the rain or often at full throttle.

## LEFT SIDE



• Drain the deposits into a suitable container by pinching the crankcase breather tube (1).

(1) crankcase breather tube