

# Index

---

|                           |         |
|---------------------------|---------|
| spark plug .....          | 79      |
| specifications .....      | 143     |
| stand, side .....         | 19, 102 |
| start button .....        | 18      |
| starting, engine .....    | 30      |
| stop switch, engine ..... | 18      |
| stopping engine .....     | 33      |
| storage .....             | 123     |
| suspension,               |         |
| front .....               | 84      |
| rear .....                | 85      |

## T

|                    |     |
|--------------------|-----|
| throttle           |     |
| freeplay .....     | 71  |
| operation .....    | 18  |
| tires,             |     |
| air pressure ..... | 98  |
| flat .....         | 133 |
| replacing .....    | 101 |
| tools .....        | 53  |

|                                 |        |
|---------------------------------|--------|
| towing .....                    | 35     |
| training, rider .....           | 3, 162 |
| transporting .....              | 121    |
| troubleshooting, starting ..... | 129    |

## U

|                           |     |
|---------------------------|-----|
| unexpected problems ..... | 127 |
|---------------------------|-----|

## V

|  |     |
|--|-----|
| vehicle identification no. (VIN) ..... | 142 |
|--|-----|

## W

|                               |     |
|-------------------------------|-----|
| warranty,                     |     |
| coverage .....                | 159 |
| extended .....                | 159 |
| service .....                 | 160 |
| washing your motorcycle ..... | 116 |
| weight limit .....            | 9   |
| wheels .....                  | 93  |