




Remove the gearshift pedal link pinch bolt and gearshift pedal link from the spindle.



Remove the bolts and left footpeg holder.



Remove the bolts and drive chain case.



Remove the swingarm pivot nut.

