



FUEL LINE

Remove the top shelter (page 3-16).
 Remove the fuel tank front mounting bolts.



Disconnect the fuel tank drain hose from the hose joint as shown.
 Lift the fuel tank as shown.



Support the fuel tank using a suitable support as shown.

