

SERVICE INFORMATION	3-1	DRIVE CHAIN	3-22
MAINTENANCE SCHEDULE	3-3	BRAKE FLUID	3-26
FUEL LINE	3-5	BRAKE PAD WEAR	3-27
THROTTLE OPERATION	3-5	BRAKE SYSTEM	3-27
AIR CLEANER	3-6	BRAKE LIGHT SWITCH	3-29
SPARK PLUG	3-8	HEADLIGHT AIM	3-29
VALVE CLEARANCE	3-12	CLUTCH SYSTEM	3-30
ENGINE OIL/OIL FILTER	3-17	CLUTCH FLUID	3-30
ENGINE IDLE SPEED	3-20	SIDE STAND	3-31
RADIATOR COOLANT	3-20	SUSPENSION	3-31
COOLING SYSTEM	3-20	NUTS, BOLTS, FASTENERS	3-32
SECONDARY AIR SUPPLY SYSTEM	3-21	WHEELS/TIRES	3-33
EVAPORATIVE EMISSION CONTROL SYSTEM (CALIFORNIA TYPE ONLY)	3-22	STEERING HEAD BEARINGS	3-33

SERVICE INFORMATION

GENERAL

▲WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.
- When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

- Place the motorcycle on a level ground before starting any work.

SPECIFICATIONS

Unit: mm (in)

ITEM		SPECIFICATIONS
Throttle grip free play		2-6 (1/16-1/4)
Spark plug		'99: CR9EHVX 9 (NGK)
		After '99: IMR9A-9H (NGK)
Spark plug gap		0.80-0.90 (0.031-0.035)
Valve clearance	IN	0.16 ± 0.03 (0.006 ± 0.001)
	EX	0.22 ± 0.03 (0.009 ± 0.001)