

MAINTENANCE

AFTER '99:

Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult their authorized HONDA dealer.

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING (NOTE 1)								REFER TO PAGE	
			× 1,000 mi	0.6	4	8	12	16	20	24		
			× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4		
* FUEL LINE											3-5	
* THROTTLE OPERATION					I			I			3-5	
* AIR CLEANER		NOTE 2						R			R	3-6
* SPARK PLUG												3-8
												3-12
* VALVE CLEARANCE									I			3-12
ENGINE OIL			R			R			R		R	3-17
ENGINE OIL FILTER			R			R			R		R	3-17
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	I	I	3-20
RADIATOR COOLANT		NOTE 3									R	3-20
* COOLING SYSTEM									I		I	3-20
* SECONDARY AIR SUPPLY SYSTEM									I		I	3-21
* EVAPORATIVE EMISSION CONTROL SYSTEM		NOTE 4							I		I	3-22
DRIVE CHAIN												3-22
BRAKE FLUID		NOTE 3										3-26
BRAKE PADS WEAR												3-27
BRAKE SYSTEM			I						I		I	3-27
* BRAKE LIGHT SWITCH									I		I	3-29
* HEADLIGHT AIM									I		I	3-29
CLUTCH SYSTEM									I		I	3-30
CLUTCH FLUID		NOTE 3							I		R	3-30
SIDE STAND									I		I	3-31
* SUSPENSION									I		I	3-31
* NUTS, BOLTS, FASTENERS			I						I		I	3-32
** WHEELS/TIRES									I		I	3-33
** STEERING HEAD BEARINGS			I						I		I	3-33

* Should be serviced by your HONDA dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the official HONDA shop manual.

** In the interest of safety, we recommend these items be serviced only by your HONDA dealer.

- NOTES:
- At higher odometer reading, repeat at the frequency interval established here.
 - Service more frequently when riding in unusually wet or dusty areas.
 - Replace every 2 years, or at the indicated odometer interval, whichever comes first. Replacement requires mechanical skill.
 - California type only.